Published in final edited form as:

Bio Protoc. ; 5(2): . doi:10.21769/BioProtoc.1381.

***In vitro* Dynamic Model of a Catheterized Bladder and Biofilm Assay**

Mario Maierl, Michael Jörger, Patrik Rosker, and Andreas Reisner*

Biomedical Science, University of Applied Sciences, Graz, Austria

Abstract

Biofilm formation on catheters is thought to contribute to persistence of catheter-associated urinary tract infections (CAUTI) which represent the most frequent nosocomial infections. Understanding of factors relevant for CAUTI pathogenesis and evaluation of new therapeutics or interference strategies requires a model system that mirrors the physico-chemical conditions prevailing in a catheterized human bladder. The described *in vitro* dynamic model of a catheterized bladder enables to emulate many of the characteristics of a catheterized human bladder albeit in the absence of a bladder epithelium. A minor modification compared to the original model system (Stickler, *et al.*, 1999) allows temperature maintenance of the top 10 cm of the catheter, thereby enabling reproducible monitoring of biofilm formation on the internal catheter surface.

Materials and Reagents

1. NaCl (Carl Roth, catalog number: 9265.1)
2. 70% ethanol
3. dH₂O
4. NaCl (Carl Roth, catalog number: 9265.1)
5. Tryptone (Carl Roth, catalog number: 8952.3)
6. Yeast extract (Carl Roth, catalog number: 2362.2)
7. Agar-agar (Carl Roth, catalog number: 5210.2)
8. Na₂SO₄ (Carl Roth, catalog number: 8560.1)
9. CaCl₂·2H₂O (Carl Roth, catalog number: CN93.1)
10. MgCl₂·6H₂O (Carl Roth, catalog number: 2189.1)
11. NaCl (Carl Roth, catalog number: 9265.1)
12. Na₃C₆H₅O₇·2H₂O (Carl Roth, catalog number: 3580.1)
13. (COONa)₂ (Carl Roth, catalog number: 4267.1)
14. KH₂PO₄ (Carl Roth, catalog number: 3904.1)

*For correspondence: andreas.reisner@fh-joanneum.at.

15. KCl (Carl Roth, catalog number: 6781.1)
16. NH_4Cl (Carl Roth, catalog number: K298.2)
17. Urea (Carl Roth, catalog number: X999.3)
18. Tryptic soya broth/CASO medium (Carl Roth, catalog number: X938.1)
19. Gelatine (Carl Roth, catalog number: 4582.2)
20. NaOH (Carl Roth, catalog number: 6771.1)
21. LB medium (see Recipes)
22. LB agar (see Recipes)
23. Artificial or human urine (see Recipes)

Equipment

1. Peristaltic pump for urine filtration (*e.g.* Heidolph Instruments GmbH, model: Pump drive 5006)
2. 10 L polycarbonate carboy for urine reservoir (*e.g.* Thermo Fisher Scientific, Nalgene®, 10 L PC with polypropylene cap with three inlets)
3. SARTORIUS P Midi Cap filter cartridge (sartorius, catalog number: 5235307H9)
4. Peristaltic multi-channel pump for urine feed (Watson-Marlow Pumps Group, model: 205U)
5. Borosilicate Glass bladder models (Figure 1) (Georg Becker Laboreinrichtungen GmbH & Co KG, www.laborbecker.at)
6. Water bath with connections for external water circle (*e.g.* LAUDA, model: E10)
7. Tripod or other holders for mounting of glass bladder models (*e.g.* Bochem Instrumente GmbH, Portable table frame TG, catalog number: TG500)
8. Silicone stopper (35 mm) with 6 mm decentralized hole
9. Glass tube (15 cm, 6 mm outer diameter = OD)
Note: We use cut 1 ml glass pipettes (BRAND).
10. Silicone tubings: 2 m (ID 3 mm, OD 5 mm)
11. Silicone tubings: 1 m (ID 9 mm)
12. Silicone tubings: 1 m (ID 5-6 mm)
13. Tygon tubings (ID 8 mm) (VWR International, catalog number: 228-1294)
14. Tube Connectors (PP, 3-5mm - 6-10 mm) (Bartelt, catalog number: 37.559)
15. T-connectors (PP) for tubings (ID 3 mm) (Carl Roth, catalog number: E763.1)
16. Urinary Catheter (all silicone Ch14) (BARD, catalog number: 153509)

17. 10 ml syringe
18. Drainage bags (*e.g.* SARSTEDT, catalog number: 74.5220.005)
19. Clamps (*e.g.* VWR International, catalog number: 229-0072)
20. Ultrasonic cleaner (BANDELIN electronic, model: Sonorex RK100H)
21. Vortex (*e.g.* VWR International, catalog number: 444-0206)
22. Recommended (air vents as breathing barrier for urine reservoir flask) (*e.g.* VWR International, catalog number: 28144-160)

Procedure

A. Preparation (Day 1)

1. Overnight cultures (ONC) of test strains in LB medium (1 ml) are grown at 37 °C/180 rpm in an incubator shaker for 16 h.
2. Autoclave bladder models, media bottle, filter cartridge, tubings and connectors prepared for the number of models you want to run (either in beakers or in aluminium foil).
3. Depending on the time frame of the experiment, artificial urine (~700 ml/day/bladder model) is prepared according to Stickler *et al.* (1999) and filtered through a 0.45 µm filter cartridge (Sartobran P) into an autoclaved bottle (Figure 2).

B. Inoculation (Day 2)

1. Prepare a culture of test strains: 0.5 ml ONC in 20 ml sterile artificial urine incubated for 2-4 h at 37 °C/180 rpm.
2. Install the heating water cycle (37 °C) and connect the urine supply tubings. Insert the tubing in the peristaltic pump (Figure 3 and Figure 4; Figure 5 for schematic representation).
3. Insert a sterile Foley-catheter in each bladder and inflate the retention balloon with 10 ml H₂O. Connect each catheter with the drainage bag.
4. Fill the urine supply system and the bladders using the peristaltic pump to a level just underneath the eye hole of the catheter (Figure 6; *Note: Check that the catheters are tight so that the bladders are not leaking!*) Stop the urine flow and clamp of the tubings after the pump.
5. Measure OD₆₀₀ of the cultures. Inoculate each model with an appropriate amount of cells for your experiment (depending on the infection phase you are interested the inoculum can range *e.g.* from 1 x 10⁶ to 1 x 10⁹ cfu). To do so remove the corresponding volume of urine from the models and replace it with the same volume of culture.

6. Remove the clamp and start the urine flow 30-60 min after inoculation (~30 ml/h, corresponds to 1.7 rpm using Watson-Marlow 205U using 5 mm silicone tubings).

C. Quantification of colonization

1. Stop the urine flow, mix or sample the bladder content and carefully remove it to completion (transfer the bladder content to a 50 ml tube). You can estimate the volume by using a balance (1 g ~ 1 ml).
2. After disconnection of the drainage tubing from the catheter, slowly deflate the retention ball. Carefully remove the catheter from the bladder and transfer it to a sterile surface. Cut away the tip of the catheter (including the eyehole) and transfer it to a microcentrifuge tube. Rinse the internal surface of the remaining catheter to remove unattached cells from bladder content with 2 ml of 0.9 % NaCl solution or sterile urine.
3. Cut and transfer 1 cm catheter segments to 1,000 µl 0.9% NaCl solution.
4. Sonicate the bladder contents and the saline solutions with the catheter pieces for 5 min (room temperature, 35 kHz, one round), then vortex for additional 2 min.
5. Dilute suspensions in 0.9% NaCl solution (bladder to 10^{-6} , catheter suspensions to 10^{-5}).
6. Plate 50-100 µl of dilutions on LB agar plates (with or without selection).
7. Following incubation calculate the colony counts to receive cfu/ml bladder content and cfu/cm catheter. In competition experiments, determine the competitive index (the ratio of harvested CFU of *e.g.* the mutant strain relative to *e.g.* the parental strain, divided by their ratio in the inoculum).

Representative data

Figure 7. Effect of random mutations on competitive bladder and catheter colonization. Dynamic catheterized bladder models were inoculated with equal amounts of *Proteus mirabilis* HI4320 wild type and transposon mutant cells HI4320mut1 and HI4320mut2, respectively. Following irrigation with artificial urine for 24 h, population distribution in the residual urine of the artificial bladder and on the internal catheter surface was determined based on CFU. CI values indicate the ratio between the mutant type and the wild type strain in the output (bladder suspension or catheter) divided by the ratio of the two strains in the

inoculum. Symbols represent CI values obtained in individual experiments, the line indicates the mean CI value.

Notes

1. Due to high variation observed with the *in vitro* model system due to varying efficiency of biofilm disintegration, experiments need to be performed in triplicate. For comparison of fitness of two strains (*e.g.* wild type and mutant), competition experiments (*e.g.* inoculating two strains in the same artificial bladder) are recommended (Reisner *et al.*, 2014).
2. Statistical Analysis: Independent challenges and co-challenge experiments are routinely analyzed using paired t-test. If a data set does not fulfill necessary criteria for a parametric test, the nonparametric Wilcoxon matched-pair test can be applied.

Recipes

1. Luria-Bertani broth (LB) and agar (1 L) (Bertani, 1951)

Mix 10 g Tryptone, 5 g NaCl and 5 g Yeast Extract

Add dH₂O to 1 L

For LB agar add agar to a final concentration of 1.5 %

Sterilize by autoclaving and store at room temperature

2. Artificial urine (Stickler *et al.*, 1999)

Add the following substances and dissolve in pre-warmed dH₂O (max. 40 °C):

	g/L
Na ₂ SO ₄	2.30
CaCl ₂ ·2H ₂ O	0.65
MgCl ₂ ·6H ₂ O	0.65
NaCl	4.60
Na ₃ C ₆ H ₅ O ₇ ·2H ₂ O	0.65
(COONa) ₂	0.02
KH ₂ PO ₄	2.80
KCl	1.60
NH ₄ Cl	1.00
Urea	25.00

Adjust pH by addition of NaOH tablets to 6.1

Add gelatine (5 g/L) and stir with heating to dissolve (max 40 °C liquid temperature)

Add autoclaved tryptic soya broth (TSB, 1 g /L) to filtered urine

Acknowledgments

Establishment of the protocol in the lab was funded by the Austrian Science Fund FWF: P21434-B18 (to A.R.). The protocol is adapted and modified from a previous protocol (Stickler *et al.*, 1999).

References

1. Bertani G. Studies on lysogenesis. I. The mode of phage liberation by lysogenic *Escherichia coli*. J Bacteriol. 1951; 62(3):293–300. [PubMed: 14888646]
2. Stickler DJ, Morris NS, Winters C. Simple physical model to study formation and physiology of biofilms on urethral catheters. Methods Enzymol. 1999; 310:494–501. [PubMed: 10547813]
3. Reisner A, Maierl M, Jörgen M, Krause R, Berger D, Haid A, Tesic D, Zechner EL. Type 1 fimbriae contribute to catheter-associated urinary tract infections caused by *Escherichia coli*. J Bacteriol. 2014; 196(5):931–939. [PubMed: 24336940]

Figure 1. Glass bladder model scheme and dimensions.

Schematic representation including length and inner diameter (ID) indications A and custom-made model B. Relevant parts are indicated: Artificial bladder compartment (1), temperature control compartment (2), connection for incoming (3) and outgoing (4) temperature control water circuit, artificial urethra for catheter insertion (5).

Figure 2. Assembly of filter sterilization for large volumes of artificial urine.

The same procedure is applicable for pooled human urine. Relevant visible parts are marked according to equipment list.

Figure 3. Connection of water cycle and urine supply.

Water bath is directly connected to the bladder models (not shown), the urine is pumped from the reservoir using a peristaltic pump (use a channel for each model). Relevant visible parts are marked according to equipment list.

Relevant visible parts are marked according to equipment list.

Figure 5. Schematic representation of the closed system necessary for setup of a catheterized bladder model.

For simplicity, one bladder without mounting equipment or water bath are shown. Relevant parts are marked according to equipment list.

A **B** sterile
urine

Eyehole

Retention
ball

cathete

Figure 6. Close up of artificial bladder model after catheter insertion and filling **A** and after cultivation **B**.

Relevant parts are indicated.