may be an adherent scar behind the bone, a good end-bearing stump often results. If the patella can be securely fixed to the end of the bone so much the better.

The general objections to exarticulations apply to the knee-joint. Not many such stumps are satisfactory.

In the leg below the knee the most favourable site is the lower part of the middle third. The old seat of election about four inches below the joint was intended for kneeling legs. Nowadays kneeling legs are avoided and only used when a stump below the knee is too short to work a socket. With skilled fitting, however, even very short stumps are useful. A good gait has been obtained with as little as two and a half inches of tibia, but this was an exceptional case. Rarely is a good result obtained with less than three inches, and then generally the stump should be capable of end-bearing. Much depends on the bulk of the soft parts. When these are voluminous, the difficulty is increased.

These short leg stumps give a better gait than is got with a kneeling leg, and the artificial limb is less unsightly. Amputation in the lower third of the leg seldom gives a satisfactory stump. The bone surface at the end is too small for good weight-bearing, and the skin is often badly nourished, cold and cyanotic.

No one can deal with many below-knee stumps without being struck by the frequency with which the fibula is cut longer than the tibia. This constitutes an obstacle to successful fitting. The fibula bears pressure on its end very ill, and often it wobbles about and is insecure.

Although many patients with Syme's amputation ask to have one performed higher up, it is deserving of its great reputation. If properly done it gives a painless weight-bearing stump. The bones should be sawn through well above the internal malleolus so as to avoid too bulbous a stump, and care should be taken to make the section at right angles to the long axis of the whole leg and not at right angles to the often incurved lower fourth. Otherwise a varus stump is likely to result. Too low a section leaves no room for a strong transverse ankle-joint, and a too voluminous heel-flap means an unsightly artificial foot and boot.

Of Pirogoff's amputation our experience at Roehampton is small and unfavourable. If the os calcis is not united to the tibia by bone it will sooner or later tilt over, and cause pain, and in any case the stump is too long for the fitting of the best type of foot.

Chopart's amputation gives a good bearing surface, but generally the calf muscles pull up the heel and tilt the lower end downwards, and painful pressure on the scar results. The stump is too short to give a spring to the gait, and it is wellnigh impossible to fix any prolongation on to it. It has no advantage over a Syme, and I would submit that if the metatarsus cannot be saved nothing below a Syme is worth doing.

In conclusion, let me disclaim all intention of laying down the law on this subject. I offer the foregoing opinions for what they are worth as the result of the impressions made upon my mind by what I have observed at Queen Mary's Convalescent Auxiliary Hospitals.

During the past two years, and particularly during the past eight months, I have had exceptional opportunities of studying the results of other men's labours, and I have the greatest admiration for the excellent results achieved, often in most unfavourable circumstances.

DEMONSTRATION.

BY

R. C. ELMSLIE, M.S.LOND., F.R.C.S.ENG.,

MAJOR R.A.M.C.(T.).

SURGEON TO QUEEN MARY'S HOSPITALS, ROEHAMPTON, AND ORTHOPAEDIC SURGEON TO ST. BARTHOLOMEW'S HOSPITAL, LONDON.

When the hospital for fitting limbs at Roehampton was started in the summer of 1915, not only was the supply of artificial limbs from limb-makers in this country totally inadequate for the requirements brought about by the war, but the types of limbs available were by no means perfect, so that a very great deal of experimental work had to be done, more particularly upon artificial arms. The limbs demonstrated were all provided at Roehampton, and, without attempting to illustrate every type of limb in use, represented a series of typical examples of the work there.

As far as the arms were concerned, they showed an immense mechanical advance upon the very elementary types alone available in London at the beginning of the war.

The function of an artificial leg is to give good stability in standing and walking and a natural gait. Hence the important points are: The way in which weight is borne upon the leg; the way in which the leg is built to secure stability; and the way in which the knee and ankle are controlled. A stump may take its bearing either upon its termination (end-bearing) or upon the bony prominences around the proximal joint. End-bearing is a quantity varying not only between stumps at different levels but also in individual stumps at the same level. In general, end-bearing, either complete or partial, may be expected when the bone section is through cancellous bone, when the bone is covered with thick skin and muscle or fascia, and when the skin over the stump is itself naturally adapted to weight-bearing. The type of end-bearing stump is that given by Syme's amputation. The other bearings used should be those upon the tuberosity of the ischium and upon the head of the tibia. Although a certain amount of bearing may be taken by fitting the stump tightly and so getting circumferential pressure upon it, yet this must not be trusted to any great extent, as by this method the skin is apt to be stretched tightly over the end of the stump, and if the scar is terminal or the skin thin this may result in ulceration.

POINTS IN THE FITTING OF A LIMB FOR AMPUTATION: LOWER LIMB.

Thigh.

For amputation through the thigh the limb is generally suspended by a sling over the shoulders, the lower end of which is attached to the leg below the knee either directly or by passing over a pulley. In this way it acts as a knee-extending mechanism. In short stumps, however, this is insufficient to enable the stump to remain securely in the bucket and to control the limb; therefore a pelvic band is added. The mechanism used to extend the knee is of two sorts. The older one is by the use of a spring, either of rubber or of steel; it should act in such a way that the knee is only extended by it from the right angled position; if it acts from a position of greater flexion than this it will prevent the man from sitting comfortably with a flexed knee. The second method is by the use of the sling from the shoulders, which pulls upon the front of the leg piece when the shoulders are raised or when the weight of the swinging limb comes upon it, thus extending the knee. The stops which limit the movement of the knee in both directions must be so strong as to be unbreakable even when the whole weight of the body exerts its maximum leverage upon them. The ankle mechanism is a point in which the present limbs almost all show a difference from the Anglesey leg, which used to be practically the standard pattern of artificial leg in England. In the Anglesey leg a considerable amount of movement was allowed at the ankle, this movement being co-ordinated with that of the knee by an artificial tendo Achillis. In the present types of legs the movement allowed at the ankle-joint is small in range (only about 20 to 30 degrees), and this movement is stopped by the compression of springs, usually of rubber, but sometimes of steel. The smallness of the range of movement is not found to interfere with walking—in fact, the walk is quite good if there is no movement at all.

Correct building of the limb is important if stability is to be secured. Two points are essential: first, the axis of the knee-joint must be behind the line which represents the centre of gravity of the body when it is erect, and, secondly, the foot must be mounted in slight equinus (20 degrees), and must be prevented from reaching the right-angled position.

The routine material for the construction of artificial leg is still willow, and as a rule the thigh and leg pieces are constructed of single pieces of wood, appropriately hollowed out, the joints being made of steel. It is not an advantage to have very lax joints in an artificial leg; as a rule the joints are lined with a bushing of leather, by adjusting which they can be made stiffer.

Hip-joint.

Hip-joint amputations are fitted with a leather cup, which entirely encloses the stump, fitting it very accurately. It is attached to the trunk by a steel pelvic band,

to it is attached the limb by a hinge joint on the outer side, and by a steel piece which runs around on a quadrant situated upon the under surface of the leather cup on the inner side. It is possible, by placing the hip-joint far forward and the knee-joint far back, to fit a limb which is stable with both hip and knee joints free; but it is customary to fit locks to both these joints, so that the man may walk with one or other free.

Knee and Leg.

In amputations through the knee the lower end of the stump is larger than the part higher up, therefore the front of the bucket must be cut away and filled in by a lacing piece of leather or else an entire leather thigh piece must be used. In either case the leg piece is attached by outside steel joints. For amputations below the knee a wooden bucket is accurately fitted to the head of the tibia, and below the patella; the weight should be borne upon these points, although in exceptional cases it may be necessary to fit a leather thigh bucket reaching right up to the tuberosity of the ischium and taking a bearing there. In short stumps a partial end-bearing can often be taken by stretching a shelf across the bucket at the right level; in some cases it is difficult to stop the stump rubbing up and down in the bucket when the knee flexes and extends, this can be got over by fitting a leather socket closely to the stump and inserting this into the bucket. As a rule, the leg is suspended by a lacing leather corset-around the thigh, with lateral steels hinged at the knee. When a man has worn a leg for some time, however, he can often dispense with this, having the leg attached only by a narrow band of leather fastening above the knee to which the leg is hung by lateral straps. If this is done the foot must not be adjusted with too much equinus, as the equinus position of the foot tends to force the knee into a hyperextended position.

Ankle.

A Syme stump is fitted into a leather bucket strengthened with steels on either side and in front, and preferably lacing behind. The ankle-joint works against two rubber buffers as in the other types of leg. It is possible, however, to replace this mechanism by a tendon stop at the back and an anterior accumulator, and this method must be used in Pirogoff and Chopart stumps.

The Best Materials for Artificial Legs.

Two outstanding problems remain in the construction of artificial legs. First, the question of material, important both for strength and lightness, and also because the present method of hollowing a bucket out of a piece of willow requires a workman with very special skill and experience. Many other materials are now being tried—leather, plied wood, wood shavings and glue, celluloid and duralumin. The Geller leg shown at this meeting is an example of an attempt to use duralumin and to work out an easy method of fitting. The second problem is that of making a leg for a thigh amputation which will not give way under the man when his weight comes on the leg with the knee flexed. Such a leg has been recently invented but is still on its trial.

UPPER LIMB.

Artificial arms are a much more difficult problem. In general an artificial arm should be designed to take the place of the left arm in work. It is obvious that it must be adapted to the particular needs of the man, and we must either have a large series of arms at our disposal, or else we must be able to build the arm out of stock parts in a variety of ways. An artificial arm need not be an entirely passive appliance; movements can be transmitted to it by tension put upon cords. In this way three pulls can be exerted: (1) by expansion of the chest, (2) by rounding the shoulders, (3) by elevation of the shoulder. These cords can be used to activate the elbow-joint, to lock and unlock this joint, and to work a mechanical hand or appliance used in its place.

Above Elbow.

An arm for amputation above the elbow must be attached by a harness which passes over the shoulder; this should

limit the shoulder movements as little as possible, so that any considerable enclosure of the shoulder is bad. The arm and forearm parts must be connected at the elbow by a hinge joint with a lock which fixes it securely and prevents movement in either direction. The alignment of the elbow-joint need not be the true one; often if the true direction of the elbow is kept the forearm will only flex straight out in front of the patient; it is more useful for it to flex more across the chest. In the mechanical arm the elbow is flexed by a cord usually activated by the pull given by rounding the shoulders. In this arm the forearm piece has the shape of the natural arm and ends in a wrist plate, to which the hand or other appliance can be attached. It is, however, often not desirable to have the cumbersome forearm thus attached; a worker's arm is made for this reason; in this the forearm is represented by a skeleton of steel, usually a rod, to which appliances can be attached. If a man who has such an arm for work wishes to have a nice-looking forearm and hand, he can adjust a show piece representing these over the skeleton. These two types of arm—the mechanical and the worker's—can be combined by making the elbow mechanical but using a skeleton forearm.

Below Elbow.

For amputations below the elbow a simple socket is used connected to an arm corset by lateral steel joints, or, in the case of longstumps, by lateral leather straps. In a new arm made by Williams of Swansea a very simple method of fitting is adopted, the elbow is kept permanently slightly flexed, the socket is fitted to the forearm stump and held on by a continuation upwards of firm leather which laces around the condyles of the humerus; this gives a very secure hold for a working arm.

Shoulder.

In amputations through the shoulder a close fitting over the shoulder is necessary; there may be a shoulder-joint inserted, but this is usually omitted. In order to allow the arm to point in various directions a movement of rotation around a vertical axis is allowed in the arm above the elbow.

Wrist.

In wrist amputations and other amputations low down in the forearm it is important to preserve the movements of pronation and supination. It may be possible to do this by omitting the steel joints at the elbow, but if this is not possible the movement can be secured by the pronation arm made by Hobbs, in which ball-and-socket joints allow the forearm socket to rotate upon the elbow.

For working men appliances fitted to the wrist plate are generally more useful than a hand. The number of appliances made is very large; they may be divided into the following classes: (1) Simple hooks, rings, and grips, without movement. (2) Similar appliances in which there is mobility in one or more directions representing wrist movements. (3) Grips opened or closed by the pull of a cord from the shoulder. Many of the appliances invented by Adams, Hobbs, and Anderson will be seen on the arms worn by the men present.

The hand is not so useful in mechanical work as the appliance, but for men in professional work a good hand is essential. In most cases the hand supplied is a simple one with a spring grip to the thumb and often with the ring and little fingers curved into a hook and reinforced for carrying. But mechanical hands are possible and useful for certain men. The first essential in a mechanical hand is that the grip should not be a simple spring grip, which will always be forced by a very slight leverage from without; the mechanism should be such as cannot be forced except by breaking the hand. Such a mechanism has been invented in a very simple and light form by Hobbs, and adapted to a number of different shaped hands. In order that the hands or appliances may be removed at will, and replaced by others, it is essential that they should all be detachable. For long at Roehampton, whilst insisting upon detachability, we obtained it by screwing in the appliances, using a screw of standard size. But it is evident that quick detachability will be desirable; for this reason the screw method is being replaced by others. Simple methods giving quick detachability will be seen in Hobbs arms.