50 to 100 yards around are shattered. A plate glass window 40 ft. from a bomb explosion showed multiple stellate fractures, a frost-like arborescent appearance being produced. Wooden shutters and doors at 30 ft. distance have been perforated, whilst in others bomb fragments have been found embedded. Pieces have been driven along parallel to the ground in through (Continental) cellar doors and windows, injuring people within. A bomb bursting in the street would send fragments through the ground floor and first floor windows, but not through the masonry. Safety lies in keeping against the wall, indoors on the ground floor, out of the line of windows.

(b) *Houses*.—The usual 20 lb. bomb employed from an aeroplane will go through an ordinary roof and explode in the top room. We have not found one which has penetrated further. A wire splinter-proof netting would cause the bomb to explode outside, and only some fragments would probably come through the roof. Sand also acts as a good protective, but its weight precludes its use on most roofs.

A bomb came through the roof of an ordinary dwelling house and exploded in the top room, wrecking everything in it, but no fragments penetrated the floor below.

A bomb struck the projecting ledge of a house roof and burst, dislodging some tiles and bricks, blowing in the windows, damaging property in the upper rooms, and the fragments spent themselves in the street below, killing two soldiers who had taken protection in a doorway. Such doorways and passages afford little protection.

A bomb, with either a forward or lateral deflection, struck the front of a house and destroyed a good deal of the masonry, and wrecked furniture, etc., within. Fortunately no one was injured.

(c) *Sheds*.—The glass and wooden roof of a large shed (a hangar) was pierced by a bomb, which must have exploded just after entry. The fragments were driven downwards, perforating in many places a canvas covering, and killing two people below. No others were injured.

(d) *Sand*.—We have records of six bombs exploding on a sandy beach. The hole produced is usually $3\frac{1}{2}$ to $4\frac{1}{2}$ ft. wide and 1 to 2 ft. deep. Case fragments are found embedded in the sides of the crater. On explosion a spray of wet sand is carried laterally for a distance of 30 ft. Bags full of sand form an ideal protection on a bomb-proof shelter.

(e) *Shipping*.—A bomb fell on a barge, and, exploding, made a hole in it, causing it to sink rapidly.

PRECAUTIONS TO BE TAKEN DURING HOSTILE AERIAL RAIDS.

On head quarters being notified of the approach of enemy aircraft, warning signals should be given to the community, such as the firing of a gun, hoisting of a flag on the town hall, blowing of a ship's siren, use of a military rattle, etc. Orders should be given beforehand that all except those connected with anti-aircraft defence must seek cover indoors, preferably in basement cellars, or, failing these, on the ground floors, away from the line of windows. "Get in and get under" is the motto for safety. It must be remembered that it is extremely difficult for the onlooker below to gauge with any accuracy the position of the aeroplane relative to his position on the ground. The danger zones are, as a rule, immediately in front of, and lateral to, the approaching aeroplane; the areas of safety lie directly behind its flight. But it must not be forgotten that a well-banked turn may quickly alter the aeroplane's direction and so place an individual below in the danger area. Fire stations should be notified, and doctors, first-aid crews, and ambulances made ready on telephonic communication. School children should not be sent home from school but congregated on the ground floors out of the line of windows. If people flock into the streets to watch events, they are exposed to as much danger from falling anti-aircraft missiles as from the enemy's bombs, and needless casualties will ensue. On no account must unexploded bombs be handled or touched; a guard should be put over them and the nearest authorities notified. Houses that require to be specially protected should have a splinter-proof netting arranged over, and some feet above, the roof. This would cause the bombs to explode outside the roof, and only a few fragments would probably penetrate the roof. Sand in bags can be used if its weight can be sustained. As hospital ships must at times be in ports which are liable to aerial attacks, we recommend that such ships that have their wards directly under the upper

deck should make use of a similar splinter-proof netting. In houses the best protection is afforded by underground cellars, especially those built under the foot-path and not directly under the house. In Continental cellars, which are partly above the street level, people are safe if they keep away from the cellar window, door, or grating, as the case may be. The same applies to the ground-floor room of an ordinary house. Avoid upper rooms, windows, and doorways. In the street, passages and entrances to shops, etc., afford no protection, and are to be avoided. If a passage open at both ends is one's only shelter, it is better to take the centre of it and lie down.

The precautions to be taken in buildings where there are more or less large collections of people, such as factories, schools, works, barracks, etc., depend upon the size and type of the building. When there are upper stories the individuals should be collected on the ground floor, with the same precautions as for a house. When there are no upper stories and the building has a ground floor only—for example, a hangar or some hospitals—those locally in authority should see if there is in the vicinity another building affording protection. If so, arrangements should be made for occupying this on hearing the warning signal, and this should be practised and carried out as for fire drill, to avoid panic, especially so with school children. If no such safety building exists, the best measure to adopt is to build beforehand some type of bomb-proof shelter within the building. We have seen a very good one made in the large shed of a works from the available material present. The sides consisted of tins or drums containing sand or non-inflammable merchandise, the roof was of timber supported by powerful props, and on the top of this were placed bags of sand 1 ft. thick. This is almost certain, we think, to keep out all fragments of a bomb exploding, as it would, just inside the roof of the shed. Provision should be made for the interior lighting of all bomb-proof shelters, as a dark place crowded with people, who may be already in a high state of excitement, is conducive to panic. Inhabitants in towns subject to air raids paste broad strips of paper diagonally over the inside of their windows, thus preventing glass falling outward and injuring people below.

Aeroplanes, as well as airships, can and have been used on many occasions during this war for making aerial attacks by night. We have had the experience of two such enemy raids. A point worth remembering is that on a bright, clear, moonlight night an aeroplane is extremely hard to see, and almost everything is in the enemy's favour. The pilot can see well and cannot be seen; he can fly fairly low and thus make more accuracy in bomb-dropping.

AN APPLIANCE FOR USE IN SEVERE INJURIES OF THE UPPER EXTREMITY.

BY
GILBERT ARNOLD,
TEMPORARY CAPTAIN R.A.M.C.

THE difficulties in readily dealing in a satisfactory manner with severe gunshot wounds of the upper arm, elbow, and forearm, where there exist infected wounds communicating with a fracture, have led me to devise the splint or supporting apparatus which I am about to describe.

All surgeons engaged in war surgery are familiar with the practical difficulties encountered in the treatment of these cases. Broadly the main difficulties are:

(1) To immobilize the part in such a manner as to secure the fragments of a fractured bone in good position.

(2) To fit such an apparatus as shall, whilst resting and fixing the part in a favourable position, at the same time permit ready access to the wound with the minimum possible disturbance of the limb as a whole during the necessary wound treatment—for these cases require frequent irrigation and dressings.

(3) To fit an apparatus which is comfortable to the patient, and which permits him, if he is in bed, to change his position from time to time without pain.

In regard to (3) some of the appliances and methods one sees in use, whilst perhaps satisfactory from a mechanical point, leave the patient all the time in relative discomfort.

I employ a rectangular plate about 45×38 cm., usually a plate of perforated aluminium 4 to 5 mm. in thickness (vide Figs. 1 and 2). This plate, splint, tray, or supporting appliance can be fashioned from other material than

FRONT VIEW
PERFORATED ALUMINIUM PLATE
FIG. 1.

aluminium, provided the material selected is non-absorbent, readily cleaned, sufficiently rigid as not to bend in use, and light in weight. Fig. 4 is a drawing of a plate made from sheet vulcanite fibre, set in an aluminium frame to give the necessary stiffness.

Originally I used to fasten the arm to the perforated splint by means of flexible aluminium hooks moulded to the contour of the arm, the hooks being fixed in the plate by screwing on small nuts underneath the plate to their reduced projecting ends. In Fig. 1 a hook of this kind is seen between the thumb and index finger.

Mode of Use.

Figs. 1, 2, and 3 are drawings made from patients. Fig. 1 is that of a compound comminuted fracture at

SIDE VIEW
FIG. 2.

the upper and middle third of the shaft of the humerus, communicating with large discharging wounds on the inner and outer side of the arm. The sketch shows the usual way in which the arm rests upon the splint. It will be noted that one corner of the splint is fitted close into the axilla, and here the upper arm is secured to the plate by means of a fold of gauze passing through holes in the plate on either side of the limb just below the shoulder. Extension is obtained in part by the weight of the limb below the fracture, but is assisted by the tension of the pad and band at the bend of the elbow, which secures the arm to the lower posterior corner of the support. At this point I often employ an elastic band, but frequently a strip of ordinary bandage suffices. The hand and forearm are maintained in a position midway between pronation and supination. As shown in Fig. 2, a cushion in the axilla is interposed between the splint and the thorax, the cushion being kept in position by attachments which pass over the opposite shoulder. The plate and limb together are well slung up, as indicated in the drawings, and in the early stages of very severe injuries the patient should be in bed with the splint in an inclined position resting on a firm pillow. If there is a wound on

the surface of the limb towards the plate the latter should be fenestrated at the corresponding area in order to allow the necessary frequent dressings to be done without removing the injured member from its supporting splint.

In the case of fractures of the forearm with shortening and displacement of the fragments, the splint is applied in the way already described, but extension and counter-extension will be required, and the splint affords an

FIG. 3.

efficient and easy means for this. The hand is to be firmly and comfortably attached, using a starch bandage, to the post shown in Figs. 3 and 4, or alternatively a bracelet of gutta-percha fastened to the plate is made to encircle the wrist. The upper arm is then pulled directly backwards, and the elbow backwards and downwards as shown in Fig. 3.

This splint does, in fact, afford a very complete degree of rest to the entire musculature of the upper extremity, and that without being burdensome by any exaggerated restraint imposed, for whilst it provides very perfect immobilization, it opposes little restriction to movements of other parts of the body—a point on which the comfort of the patient depends so much.

I can confidently recommend this simple appliance as an instrument giving—to the patient—great comfort, and—to the surgeon—a great control of the situation. It enables the surgeon to apply correcting forces in any

FIG. 4.—A. The hand is attached to this post if it is necessary to make extension on the forearm. B. Fits axilla here.

desired directions to meet the exigencies and special deformities of each particular case, for the margins of the plate and the perforations are so many fulcra for the effective application of power.

I am indebted to that excellent artist, Corporal Bernhard Hugh, Royal Flying Corps, for kindly making the drawings which illustrate this article whilst himself a patient.

THE convention of the Cremation Association of America will be held at Cincinnati on August 24th and 25th. Among the questions proposed for discussion is the advisability of adopting an insurance scheme to provide for the incineration of the bodies of deceased members. Dr. Hugo Erichsen of Detroit, who has been president for three years, announces his definitive retirement from that position.