Published in final edited form as:

Hosp Pediatr. 2015 March ; 5(3): 160–163. doi:10.1542/hpeds.2014-0123.

A framework for reducing alarm fatigue on pediatric inpatient units

Amogh Karnik, MSc, BSE^{1,2} and Christopher P. Bonafide, MD, MSCE^{2,3,4,5}

¹The Commonwealth Medical College, Scranton PA

²Division of General Pediatrics, The Children's Hospital of Philadelphia, Philadelphia PA

³Center for Pediatric Clinical Effectiveness, The Children's Hospital of Philadelphia, Philadelphia PA

⁴Perelman School of Medicine at the University of Pennsylvania, Philadelphia PA

⁵Leonard Davis Institute of Health Economics, University of Pennsylvania, Philadelphia PA

Keywords

alarm fatigue; clinical alarms; false alarms; physiologic monitoring

On my first day on the patient floors as a medical student, I couldn't help but notice the buzzing, beeping, cacophony of alarms that ostensibly indicated impending danger for just about every patient on the unit. I looked around, waiting for someone—a nurse, a doctor, anyone—to react. But thus far in my brief career, I've come to learn that most of the alarms I hear do not indicate emergencies, and in fact most do not warrant any clinical intervention at all. As a result, the buzzing and beeping fades into the background now.

Context

Physiologic monitor alarms are intentionally designed to immediately alert clinicians to any deviation from the norm, regardless of the quality of the signal or cause of the deviation.¹ In theory, this design ensures that doctors and nurses will always be informed of physiologic changes in order to respond to important deterioration events quickly.

However, we know that monitors generate very frequent alarms (39-352 alarms per patient, per day)²⁻⁹ and that a high proportion are false, defined as not being actionable (over 90% of pediatric intensive care unit^{2,3} and over 70% of adult intensive care alarms).^{6,7} The task of separating the true, actionable alarms from the false or non-actionable alarms falls to the clinicians responsible for responding to alarms, who in most settings are nurses.

Address correspondence to: Christopher P. Bonafide, MD, MSCE, The Children's Hospital of Philadelphia, 34th St and Civic Center Blvd, Suite 12NW80, Philadelphia, PA 19104. bonafide@email.chop.edu, 267-426-2901.

Financial disclosures: The authors have no financial relationships relevant to this article to disclose.

Conflicts of interest: The authors have no conflicts of interest relevant to this article to disclose.

But we rely on nurses for a myriad of other important responsibilities that we really care about, from administering antibiotics to a septic child, to discharging a kid with asthma in order for their mother to pick up their inhaler before the pharmacy closes. Thus, nurses are forced to make difficult decisions on a nearly continuous basis about whether to respond to alarms from different patients, or to continue with the tasks at hand, assuming that the alarms do not require their immediate attention.

For example, consider a nurse in the midst of suctioning a patient while gowned and gloved, when she hears an alarm go off on her other patient across the hall. At that point, the nurse has to decide which task is more important: either to continue suctioning this patient or stop suctioning, remove her gown and gloves, and check to see if her other patient is having a life-threatening event. If that patient has produced many false alarms before, the nurse may rely on her prior experiences to assume that this alarm has a low probability of requiring her immediate attention, finish the suctioning, and then respond to the alarm several minutes later. This tendency can have consequences, as nurses may become accustomed to responding slowly or even ignoring alarms altogether, since it is so uncommon for alarms to require intervention. This effect is known as *alarm fatigue*.

Alarm fatigue is not a new problem, but recently it has received a great deal of attention in hospitals throughout the United States. In 2013, The Joint Commission issued a Sentinel Event Alert that named frequent exposure to non-actionable alarms “the most common contributing factor to alarm-related sentinel events.”¹⁰ Soon after, they released a National Patient Safety Goal to their more than 3,300 accredited hospitals, requiring implementation of measures to improve alarm management by 2016.¹¹

Non-actionable alarm types

Non-actionable clinical alarms fall into 2 main categories. First, they can be “invalid,” meaning they do not reflect the actual physiologic status of the patient. An example is a pulse oximetry alarm in a happily wheezing baby with bronchiolitis who is kicking his legs around, causing motion artifact. The second type of non-actionable alarm is the nuisance alarm, which does reflect the actual physiologic status of the patient but does not require clinical intervention.¹² An example is a desaturation to 89% with a good quality waveform that self-resolves within 5 seconds. If a patient repeatedly triggers these types of alarms, nurses can easily become desensitized and choose to complete other tasks prior to addressing the alarm, or ignore the alarm altogether.

Proposed framework for reducing alarm fatigue

That said, what can be done to minimize the potential for alarm fatigue in pediatric settings, and how can this complex problem be addressed on our inpatient units? Below, we propose a series of different categories of interventions that together form a framework for alarm fatigue reduction on pediatric inpatient units. The framework, conceptualized as a sequential series of intervention steps, includes: (a) monitoring only the patients at significant risk of a life-threatening event, (b) reducing invalid (artifact) alarms, (c) reducing nuisance (valid but non-actionable) alarms, and (d) improving alarm notification for the remaining actionable alarms.

Monitor only the patients at significant risk of an immediate life-threatening event

According to American Heart Association (AHA) guidelines, pediatric continuous electrocardiographic (ECG) monitoring—aimed primarily at detecting arrhythmias—is indicated for just a small fraction of patients who we care for on pediatric hospitalist-led teams outside the ICU.¹ For patients without known heart disease, they note that monitoring may be beneficial, but is not essential in children with chest pain, blunt chest trauma, acute neurological events, severe asthma exacerbation, Kawasaki disease, those administered drugs with potential for QT prolongation, those being evaluated for syncope (which we would extend to apparent life threatening events), and infants with prenatal exposure to cocaine (putting them at risk of coronary vasospasm).

Similar to ECG monitoring, 1 of the 5 recommendations on the Pediatric Hospital Medicine Choosing Wisely list is “Don’t use continuous pulse oximetry routinely in children with acute respiratory illness unless they are on supplemental oxygen.”¹³ Based on the AHA and Choosing Wisely recommendations, a first step that we can take now is to develop consensus guidelines at our institutions for initiating continuous ECG and pulse oximetry monitoring. One potential implementation strategy is to include the appropriate indications in a drop-down menu when monitoring is ordered in an electronic health record as a means of providing clinical decision support and reinforcing appropriate use.¹⁴

A second area where we can improve care and reduce unnecessary monitoring is to develop standards on how best to discontinue monitoring in patients who no longer need it. One effective way to do this that is analogous to the way we order many medications is to include a duration in the monitoring order based on the patient’s initial condition and severity of illness. For example, an initial order for monitoring could include a duration of 24 hours, with a prompt for the nurse to reassess the need and contact the physician once the order expires if they believe that discontinuing monitoring would be unsafe.¹⁴

Reduce invalid (artifact) alarms

Invalid alarms from artifact are usually caused by poor contact between the sensor and the skin, which may be due to the sensor’s adhesive drying out or the patient moving. Among patients in whom monitoring is necessary while they are awake and active, interventions that have been successful in reducing these alarms include meticulous skin preparation and changing electrodes every 24 hours.¹⁵

Reduce nuisance (valid but non-actionable) alarms

Nuisance alarms occur mainly when the alarm thresholds used to trigger alarms are set at levels at which clinicians would not intervene, or when the alarm thresholds are set at appropriate actionable thresholds but the amount of time the patient spends outside the threshold is very brief and resolves spontaneously. First and foremost, alarms are designed to indicate emergencies, and should summon staff to the bedside immediately. So, the first step is to identify thresholds at which there is little ambiguity that a valid alarm beyond that threshold indicates an emergency: a condition for which an intervention is necessary.¹⁶ One reasonable starting point is to use published data from hospitalized children to choose age-based cut points for heart and respiratory rates¹⁷ (for example, using the 1st and 99th

percentiles for age, or even more extreme values) and an actionable threshold for pulse oximetry that represents an emergency (for example, < 80%).¹⁸

After thresholds are chosen, they can be adjusted further based on the patient's physiology to minimize non-actionable alarms. Since nurses are primarily responsible for responding to the alarms themselves, they often have excellent insight into whether a patient's parameters are effective based on their unique conditions, and if those parameters should be adjusted. Although policies may vary from institution to institution, it may be beneficial to expand the responsibilities of the nursing staff to allow nurses to change alarm parameters within a margin considered safe (for example +/- 10% from the originally ordered settings) without a physician order provided that physicians and the rest of the team caring for that patient are notified and the change is documented.

The next step is to consider instituting a delay in the interval of time between when a threshold is crossed and when the alarm fires. The aim of this intervention is to reduce frequent alarms for brief and self-limited breaches of the thresholds. One technology for implementing pulse oximetry alarm delays called SatSeconds (for Nellcor devices) takes into account both the depth of the desaturation and the duration, alarming immediately for major desaturations while delaying alarms for less significant drops.¹⁹

Improve alarm recognition and notification for the remaining actionable alarms

Once interventions have been implemented to improve the signal-to-noise ratio by reducing the noise (invalid and nuisance alarms), we can turn our attention to strengthening the signal (actionable alarms). Alarms cannot be useful if no one hears them or recognizes their acuity. As inpatient units expand to become more spacious and hospitals convert multi-patient rooms into private rooms flanking long hallways, it gets harder and harder for staff to hear and recognize alarms. Two potential approaches to address this problem that can be considered include secondary notification systems and the employment of monitor watchers.

Secondary notification systems pass alarm information from the monitor system to the nurse's pager or wireless telephone system using a network interface.²⁰ These systems allow the hospital to configure which alarms pass through to the mobile device, and which alarm at the bedside only. They also allow for automatic escalation of the alarm message to the charge nurse or another clinician if the primary nurse does not acknowledge the alarm within a specified timeframe.¹⁹

An additional layer of support is to employ technicians who continuously view the waveforms and alarms of many patients from a central station. These "monitor watchers" have the potential to improve care, but are expensive and few studies have demonstrated tangible improvements in patient outcomes.^{21,22}

How to get started

Above, we have outlined a wide range of interventions that can be implemented as part of a large-scale quality improvement initiative with the aim of reducing non-actionable alarms that contribute to alarm fatigue. Often the most difficult part of beginning to address a

problem like this is getting started. As a first step, we suggest getting a sense of the issue at your institution. Data on the frequency and types of alarms firing on each unit will help immensely with this, and you may find that your Biomedical Engineering Department is eager to provide this kind of data. If data are hard to come by, you could begin by conducting an audit of how many patients are on monitors, evaluating what their default settings are and if they are at actionable levels, and interviewing nurses about the ways they are alerted about alarms and how they manage them. Once you understand the problem, it will be helpful to form a multidisciplinary team that includes other physicians, nurses, biomedical engineers, and staff experienced in quality improvement in order to prioritize interventions from the menu of items above based on the most salient issues at your institution.

In summary, alarm fatigue has the potential to harm our patients. Hospitalists are uniquely positioned to directly address this complex problem with interventions that are relatively easy to implement and evaluate. We hope that the framework we have proposed above is helpful in developing new alarm management strategies. We should collaborate across institutions to identify the most effective interventions and implementation strategies to reduce non-actionable alarms and minimize the potential for adverse patient outcomes from alarm fatigue.

Acknowledgments

Funding: Dr. Bonafide is supported by the National Heart, Lung, And Blood Institute of the National Institutes of Health under Award Number K23HL116427. The content is solely the responsibility of the authors and does not necessarily represent the official views of the National Institutes of Health.

Abbreviations

AHA	American Heart Association
CT	computed tomography

References

1. Drew BJ, Califf RM, Funk M, et al. Practice standards for electrocardiographic monitoring in hospital settings. *Circulation*. 2004; 110:2721–2746. [PubMed: 15505110]
2. Lawless ST. Crying wolf: false alarms in a pediatric intensive care unit. *Crit Care Med*. 1994; 22:981–985. [PubMed: 8205831]
3. Tsien CL, Fackler JC. Poor prognosis for existing monitors in the intensive care unit. *Crit Care Med*. 1997; 25:614–619. [PubMed: 9142025]
4. Biot L, Carry PY, Perdrix JP, Eberhard A, Baconnier P. [Clinical evaluation of alarm efficiency in intensive care]. *Ann Fr Anesth Reanim*. 2000; 19:459–466. [PubMed: 10941446]
5. Borowski M, Siebig S, Wrede C, Imhoff M. Reducing false alarms of intensive care online-monitoring systems: an evaluation of two signal extraction algorithms. *Comput Math Methods Med*. 2011 pii: 143480.
6. Chambrin MC, Ravaux P, Calvelo-Aros D, Jaborska A, Chopin C, Boniface B. Multicentric study of monitoring alarms in the adult intensive care unit (ICU): a descriptive analysis. *Intensive Care Med*. 1999; 25:1360–1366. [PubMed: 10660842]

7. Görges M, Markewitz BA, Westenskow DR. Improving alarm performance in the medical intensive care unit using delays and clinical context. *Anesth Analg*. 2009; 108:1546–1552. [PubMed: 19372334]
8. Graham KC, Cvach M. Monitor alarm fatigue: standardizing use of physiological monitors and decreasing nuisance alarms. *Am J Crit Care*. 2010; 19(1):28–34. [PubMed: 20045845]
9. Siebig S, Kuhls S, Imhoff M, Gather U, Scholmerich J, Wrede CE. Intensive care unit alarms--how many do we need? *Crit Care Med*. 2010; 38(2):451–456. [PubMed: 20016379]
10. The Joint Commission. Sentinel event alert: medical device alarm safety in hospitals. 2013 Available at: http://www.pwrnewmedia.com/2013/joint_commission/medical_alarm_safety/downloads/SEA_50_alarms.pdf.
11. The Joint Commission announces 2014 National Patient Safety Goal. *Jt Comm Perspect*. 2013; 33:1–4.
12. Cvach M. Monitor alarm fatigue: an integrative review. *Biomed Instrum Technol*. 2012; 46(4): 268–277. [PubMed: 22839984]
13. Quinonez RA, Garber MD, Schroeder AR, et al. Choosing wisely in pediatric hospital medicine: five opportunities for improved healthcare value. *J Hosp Med*. 2013; 8(9):479–485. [PubMed: 23955837]
14. Dressler R, Dryer MM, Coletti C, Mahoney D, Doorey AJ. Altering overuse of cardiac telemetry in non-intensive care unit settings by hardwiring the use of American Heart Association guidelines. *JAMA Intern Med*. 2014 Sep 22. [Epub ahead of print].
15. Cvach MM, Biggs M, Rothwell KJ, Charles-Hudson C. Daily electrode change and effect on cardiac monitor alarms: an evidence-based practice approach. *J Nurs Care Qual*. 2013; 28:265–271. [PubMed: 23187092]
16. Abenstein JP, Narr BJ. An ounce of prevention may equate to a pound of cure: can early detection and intervention prevent adverse events? *Anesthesiology*. 2010; 112(2):272–273. [PubMed: 20098123]
17. Bonafide CP, Brady PW, Keren R, Conway PH, Marsolo K, Daymont C. Development of heart and respiratory rate percentile curves for hospitalized children. *Pediatrics*. 2013; 131:e1150–e1157. [PubMed: 23478871]
18. Taenzer AH, Pyke JB, McGrath SP, Blike GT. Impact of pulse oximetry surveillance on rescue events and intensive care unit transfers: a before-and-after concurrence study. *Anesthesiology*. 2010; 112(2):282–287. [PubMed: 20098128]
19. Sharkey T. Fact or artifact? Breakthroughs in pulse oximetry alarm management. *Neonatal Intensive Care*. 2003; 16(4):51–53.
20. Cvach MM, Frank RJ, Doyle P, Stevens ZK. Use of pagers with an alarm escalation system to reduce cardiac monitor alarm signals. *J Nurs Care Qual*. 2013; 28(3):265–271. [PubMed: 23187092]
21. Funk M, Parkosewich JA, Johnson CR, Stukshis I. Effect of dedicated monitor watchers on patients' outcomes. *Am J Crit Care*. 1997; 6(4):318–323. [PubMed: 9215430]
22. Zwieg FH, Karfonta TL, Jeske LJ, et al. Arrhythmia detection and response in a monitoring technician and pocket paging system. *Prog Cardiovasc Nurs*. 1998; 13(1):16–22. 33. [PubMed: 9614685]